



Ages 5+
Max. Weight: 100 kg



ASSEMBLE INSTRUCTIONS.

1. Place the Quad Clamp over the Vertical Tube of the Handlebar, then insert the Handlebar onto the fork stem.
2. Insert the long bolt through the hole on the bottom of the fork, hand tighten the bolt into the "Star Nut" which is pre-inserted into the Vertical Tube of the Handlebar.
3. Place the wheel in the middle of the fork, align the hole and insert the Front Wheel Axle through the Fork, Tighten up the axle on both sides by Allen Key.
4. Align the T-bar to the wheel, then lock the long bolt & Quad Clamp.



INSTRUCTIONS FOR USE.

- Grip the handlebars with your hands, place one foot on the board and the other foot on the ground
- Pay attention to your surroundings and make sure that your riding area is clear
- Kick backwards with your foot beside the scooter to give you motion
- Repeat this kicking action in order to stay in motion
- To stop or slow down, place your kicking foot on the brake pedal above the rear wheel or put your kicking foot on the ground
- Do not over-steer as this could cause you to fall off the scooter

WARNING

- ADULT ASSEMBLY REQUIRED
- THIS PRODUCT IS FOR AGE 5+
- MAXIMUM RIDER WEIGHT: 100 kg
- ALWAYS WEAR A HELMET, WRIST, KNEE & ELBOW PADS WHEN RIDING YOUR SCOOTER. KEEP THE HELMET CHINSTRAP SECURELY BUCKLED
- ALWAYS WEAR CLOSED SHOES WHEN RIDING YOUR SCOOTER
- RIDE ON SMOOTH, PAVED SURFACES AWAY FROM MOTOR VEHICLES AND OTHER ROAD USERS.
- AVOID SHARP BUMPS, DRAINAGE GRATES, AND SUDDEN SURFACE CHANGES. SCOOTER MAY SUDDENLY STOP
- AVOID STREETS AND SURFACES WITH WATER, SAND, GRAVEL, DIRT, LEAVES, AND OTHER DEBRIS. WET WEATHER IMPAIRS TRACTION, BRAKING, AND VISIBILITY.
- DO NOT RIDE AT NIGHT
- BRAKE WILL GET HOT FROM CONTINUOUS USE. DO NOT TOUCH AFTER BRAKING
- AVOID EXCESSIVE SPEED ASSOCIATED WITH DOWNHILL RIDES
- ADULT MUST ASSIST CHILDREN IN THE INITIAL ADJUSTMENT
- OBEY ALL LOCAL TRAFFIC AND SCOOTER RIDING LAWS AND REGULATIONS.
- WATCH OUT FOR PEDESTRIANS
- CHECK AND SECURE ALL FASTENERS BEFORE EVERY RIDE, AVOID PITCHING OR ENTRAPMENT
- THE SCOOTER IS DESIGNED FOR ONE RIDER AT A TIME. DO NOT ALLOW 2 CHILDREN TO RIDE AT THE SAME TIME
- DO NOT USE THE SCOOTER IF IT HAS ANY DAMAGE. REPLACE WORN OR BROKEN PARTS IMMEDIATELY

MAINTENANCE

- KEEP THE PRODUCT IN A DRY PLACE. IF THE SCOOTER GETS WET, DRY METAL PARTS TO PREVENT RUSTING
- CLEAN WITH DAMP CLOTH. DO NOT USE SOLVENTS OR BLEACHES FOR CLEAN
- THIS SCOOTER IS EQUIPPED WITH PRECISION BEARING WHICH WERE FILLED WITH LUBRICANT AT HIGH PRESSURE DURING MANUFACTURING. FOR THIS REASON, THE WHEELS CAN ONLY RUN EASILY AND QUICKLY WHEN THERE IS A LOAD ON THE SCOOTER. THE BEARINGS ARE MAINTENANCE FREE
- THE WHEELS SHOULD BE REPLACED WHEN THEY GET WORN DOWN
- FOR YOUR OWN SAFETY, PLEASE USE ORIGINAL SPARE PARTS ONLY. DO NOT MAKE ANY STRUCTURAL CHANGE
- SELF-LOCKING NUTS AND OTHER SELF-LOCKING FIXINGS MAY LOSE THEIR EFFECTIVENESS AFTER CUSTOMER SERVING OR REPLACEMENT PARTS. SO CHECK YOUR SCOOTER BEFORE USING IT EVERY TIME

Trick / Stunt riding and warranty

If you ride your scooter in a manner that places large forces and stresses on the product, the scooter will not be covered under warranty. The Scooter is designed to meet and exceed applicable safety standards, however the forces exerted through extreme riding will cause premature wear to all parts.

